

<b>SOP No. EM-05</b>		<b>Page 1 of 3</b>
<b>Collection of Sediment Samples</b>		
<b>Revision: #4</b>	<b>Replaces: 4/9/02 version</b>	<b>Effective: 2/13/03</b>

**1. Purpose and Scope:** Pesticides can bind to organic matter in the sediment of lakes, ponds, and streams. Sediment can become contaminated with pesticides via runoff from the land or through aerial deposition to the surface of the water. Sediment samples are collected to determine the quantity of a pesticide bound to the organic matter. Any instructions on documenting and collecting sediment samples found in the Environmental Monitoring Plan (EMP) for the Program under study supersedes instructions contained in this SOP.

**2. Supplies Required:** To request sampling equipment and other supplies to collect sediment, contact the Laboratory Supplies Coordinator at the APHIS Analytical and Natural Products Chemistry Laboratory (ANPCL), Plant Protection and Quarantine, in Gulfport, MS at (228) 822-3106.

- 2.1 weighted dredge tied to a strong rope
- 2.2 3-gallon galvanized pail
- 2.3 hand trowel
- 2.4 ¼-inch mesh screen
- 2.5 sample container (1-gallon heavy foil envelope)
- 2.6 baby wipes
- 2.7 field log book
- 2.8 ice chest with wet, dry, or blue ice (obtain locally)
- 2.9 environmental monitoring forms (APHIS Form 2060)
- 2.10 strapping tape
- 2.11 indelible marker

<b>SOP No. EM-05</b>		<b>Page 2 of 3</b>
<b>Collection of Sediment Samples</b>		
<b>Revision: #4</b>	<b>Replaces: 4/9/02 version</b>	<b>Effective: 2/13/03</b>

### **3. Collecting a Submerged Sediment Sample:**

- 3.1 Sediment is usually collected from the bottom of a water body. Stand at the edge of the water body to be sampled. Hold the free end of the rope that is attached to the clean, weighted dredge and toss the dredge into the water. Take care to maintain a firm grip on your end of the rope, otherwise the dredge and rope will be lost to the bottom of the water body.
- 3.2 Pull the dredge to you and empty the contents into the galvanized pail.
- 3.3 Repeat steps 3.1 and 3.2 until the pail is about half full.
- 3.4 Allow the sediment to settle in the pail and then pour off the water on the top.
- 3.5 Transfer the sediment sample to the sample container (1-gallon heavy foil envelope). If there is a lot of debris in the sample, pass it through the wire mesh to remove twigs, leaves, stones, and other debris prior to placing the sample in the sample container. Fold over the flap on the heavy foil bag such that there is no air space. Securely seal the bag with the strapping tape and label the bag using the indelible marker with a code that will allow the sample to be matched to its documentation.
- 3.6 Place the sample in the ice chest for transport to a freezer for storage prior to shipping.
- 3.7 Decontaminate all of the sampling equipment by first washing off any sediment adhering to it and then wiping it down with baby wipes.

### **4. Collecting a Sediment Sample from a Dry Channel or Depression:**

- 4.1 If you plan to collect sediment from the bottom of a channel or depression which contained water at one time but is now dry, contact the Environmental Monitoring Team at (301) 734-7175 for details on equipment and procedures.

### **5. Documentation:**

- 5.1 Record all observations in the field log book (see SOP EM-12, *Using a Field Log Book*). Include the GPS coordinates of the site, and a sketch showing the path that run-off water follows between the treatment site and the sample collection site (if

<b>SOP No. EM-05</b>		<b>Page 3 of 3</b>
<b>Collection of Sediment Samples</b>		
<b>Revision: #4</b>	<b>Replaces: 4/9/02 version</b>	<b>Effective: 2/13/03</b>

applicable). A topographical map or aerial photograph annotated with the required information should be provided if possible as well as photographs or video of the sample site and run-off channel. Be sure to record when the last rainfall occurred, the amount, estimated duration, time between the onset of the rain and the collection of the sediment sample, land slope, soil type, and a description of the type of vegetation growing between the treatment site and the sample collection site.

- 5.2 Complete an APHIS Form 2060 for each sediment sample.
- 5.3 Retain the pink copy of Form 2060 for your records and distribute the remaining copies as specified in the EMP.

## **6. Packaging and Shipping:**

- 6.1 Package and ship the sediment samples as described in SOP EM-17, *Packaging and Shipping of Samples*.